



Arlington Industries, Inc.

1 Stauffer Ind. Park - Scranton, Pa. 18517
800-233-4717 Fax: 570-562-0646
www.aifittings.com - E-MAIL: sales@aifittings.com
Manufacturers of Quality Electrical Products



Arlington Cat #
FLB4360BL (Black)
FLB4360BR (Brown)
FLB4360CA (Caramel)
FLB4360LA (Light Almond)
FLB4360GR (Gray)

For Canada add 'GC' suffix to CAT #s shown above

FLB4360 Floorbox Kit

Contents:

- (1) FLB4360 Mounting Bracket
- (1) FLB3500 Box
- (1) Non-Metallic Cover Plate
- (1) Gasket
- (1) Gasket Support Plate
- (1) In-Use Coverplate
- (1) Carpet Ring
- (1) NM94 Cable Connector
- (1) NM95 Cable Connector
- (3) #8 x 1/2" Long Sheet Metal Screws
- (3) #8 x 1/2" Long Flat Head Screws
- (1) #6 X 1/2" Long Screw
- (1) UL Listed 15A Duplex Receptacle

#8 x 1/2" FLAT HEAD SCREW

NON-METALLIC BLANK COVERPLATE

GASKET

#6 x 1/2" SCREW

PLASTIC GASKET SUPPORT PLATE

15A UL LISTED DUPLEX RECEPTACLE

#8 x 1/2" SHEET METAL SCREW

FLB3500 BOX

FLB4360 MOUNTING BRACKET

RECEPTACLE ALIGNMENT MARK

NON-METALLIC BLANK COVERPLATE

IN-USE COVERPLATE

CARPET RING

COMPLETED INSTALLATION

EXPLODED ASSEMBLY VIEW

All wiring must be in accordance with National (NEC/CEC), State and Local Electrical Codes.

WARNING: Make sure power is OFF at main panel before installing.

If you have any questions or if parts are missing from your FLB4360 kit, Please call our Customer Service Department at 1-800-233-4717. Do not call or return this product to your local store or distributor.

Installation Instructions:

1. Determine location for the floorbox installation, being careful to avoid structural framing members.
2. At desired location, cut 4-1/4" diameter hole thru flooring and subfloor using hole saw. If necessary, use included Carpet Ring to cover cut edges of carpet or oversized hole.
3. Place FLB4360 Mounting Bracket into hole. Align the bracket for proper receptacle orientation using indicator marks and tighten (3) wing screws to secure bracket to the floor.
4. Pull non-metallic type cable and install in FLB3500 box using supplied NM94 or NM95 cable connector.
5. Attach box to bracket using three #8 x 1/2" long sheet metal screws (provided) through the U-shaped cut-outs in FLB3500 box.
6. Wire receptacle and install in box. All wiring to be in accordance with State, Local, and National electrical codes.
7. Attach supplied gasket support plate to receptacle with #6 x 1/2 Long Screw, and install Gasket.
8. Attach coverplate to box using 3 #8 x 1/2" long flat head machine screws
9. Replace Gasket Support plate, Gasket & Blank Coverplate with included In-Use Coverplate for an in-use receptacle using supplied #6 x 1/2" long screw.